



# INSTALLATION INSTRUCTIONS for HS-10 16" WIDE WALL MOUNT HAND SINK with SIDE SUPPORT BRACKETS

## INCLUDES:

- (A) HAND SINK
  - (B) BACKSPLASH WALL MOUNT FAUCET
  - (C) WALL MOUNT BRACKET
  - (D) (2) SIDE SUPPORT BRACKETS  
(4 Screws Provided)
1. Install FAUCET (B) on HAND SINK with SIDE SPLASHES (A) and hook up water inlet leads (not provided)
  2. Mount SIDE SUPPORT BRACKETS (D) to each side of HAND SINK (A) with screws provided.
  3. Hang HAND SINK with SIDE SPLASHES (A) on WALL BRACKET (C). The SIDE SUPPORT BRACKETS (D) will rest against the wall.
  4. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.

